

# Rechargeable Stage 1 Remote Control Clever Cats User Guide (EY06338)



## Getting started with your Clever Cats

The Remote-Control Clever Cats have been designed so that younger children can enjoy practising early programming skills without having to navigate complex controls with their small hands. The cats can be used as an early control resource as they have a single large round button that makes the cats go forward and turn. This resource is not only great fun but teaches children about cause and effect, stimulus response, direction, and problem solving along with providing lots of language and communication opportunities as they play with their peers.

The Remote-Control Clever Cats have been tested for ages **10 months upwards**.

## What's included?

- 4 x Clever Cats (grey, white, black and brown)
- 4 x Remote Controls (colours match the cats)
- 1 x Docking Station
- 1 x Docking Station Charging Cable with Universal Plug Adapter (4 different types of plugs)
- 1 x Quick Visual Guide



## First things first – charging the Clever Cats

Before using the Remote-Control Clever Cats, make sure they are charged.

### Charging your Clever Cats

- Plug the charging cable into the charging port found underneath the docking station.
- Charge time: approximately 4 hours.
- A full charge provides around 3 hours of use.
- You will know that the cats are charging as their eyes will turn red. The left-hand button on the remote controllers will also turn red.
- Once fully charged, both the cat's eyes and the lights on the remote controls will turn green.

### Switching the Clever Cats and remote controls on and off

- To switch the Clever Cat on or off, slide the switch underneath the cat.
- To switch the remote control on or off, slide the switch on the underside of the controller.
- When switched on the Clever Cats eyes will turn green. The light on the left-hand side of the controller will flash green.
- Remember to switch the cats and controllers off when not in use to preserve the battery.



## Interactive Meowing feature

The Clever Cats can be used with or without sound, depending on your setting preference. The sound switch can be found underneath the cat.

When the sound is switched on, the cats will respond with a meow when stroked. Their eyes will also illuminate orange when touched, whether the sound is turned on or off.

## Using the Clever Cats

The remote controls for the Clever Cats are simple to use and have just one round button. When pressed, this button allows the cats to move forward and turn.



- Press and hold the circular black button to move the Clever Cat forwards.
- The cat will continue moving for as long as the button is held down.
- When you release the button, the cat will stop moving.
- Press and hold the black button again to make the cat turn. The cat will keep turning in a circle until the button is released and the direction of the cat is chosen.
- The next time the black button is pressed and held, the cat will move forwards in its new direction. (N.B. Each press of the button will alternate between moving forwards and turning)

## Care and maintenance

- Clean the Clever Cats using a soft, damp cloth.
- **Do not** submerge in water.
- Recharge regularly to maintain battery performance.

