

Easi-Stopwatches User Guide


(SP47468)

Twelve easy to use handy stopwatches in convenient carrycase docking station. Ideal for timing activities across the curriculum.

What is included in your pack

Each pack contains:

- 12 Easi-Stopwatches each in a different colour (blue, yellow, pink, green, orange and purple) with useful lanyards.
- Carrycase docking station for easy charging and convenient transportation.
- USB-C to USB-A cable.



Charging the Easi-Stopwatches and switching on

Before using the Easi-stopwatches, make sure they are charged. Here is some charging information.

- The Easi-Stopwatches conveniently charge in the carrycase docking station, by attaching the USB cable and plugging in.
- The Easi-Stopwatches will take approximately 5 hours until fully charged.
- Once charged they will last for approximately 3 days.
- Switch on by pressing the button on the front and this will start the timer.




Easi-Stopwatches User Guide

(SP47468)

Left and right **Top Side Button** controls for accessibility.

Split Time Function

able to store up to 40 times simultaneously for easy tracking and comparison of performances.



Adaptable Display options

include:

(hours/minutes/seconds)
(hours/minutes/seconds/tenths)
(hours/minutes/seconds/tenths/
hundredths)

Start/Pause Button to begin timing or to pause timer.
Auto sleep mode to conserve battery life after 5 minutes of inactivity.

There are two main functions:

- Stopwatch timer- measure time with a start/stop function
- Split timer- record up to 40 split times

Using the Easi-Stopwatches

Resetting the timer to zero

- Press and hold the Start/Pause button for approximately 3 seconds to reset the stopwatch back to zero.




Note – the timer will continue to run before it resets.

Easi-Stopwatches User Guide

(SP47468)

Set timer accuracy

- Press and hold the top right-side button followed by the start/pause button and hold them down for 3 seconds. The flag on the display will disappear to show that the timer's accuracy is ready to change.
- To change the timer accuracy, press the top right-side button once. The tenths zero will appear. Press the button again to display the hundredths zero. If the button is pressed a third time the display will return to minutes and seconds.
- Once the accuracy has been selected. Press the Start/Pause button.



Stopwatch timer

The Easi-Stopwatch is an easy-to-use accurate stopwatch that can measure with a precision of 1/100th of a second. This is perfect for exploring time and helping develop understanding of different units of time.

Start the timer

- Press the Start/Pause button (shown on the diagram above) and the timing will begin.

Pause the timer

- Press the Start/Pause button again to pause the timer and view the current time.

Easi-Stopwatches User Guide

(SP47468)

Split timer

Split times are cumulative meaning they show the total time passed and record intermediate times within that time without stopping the overall timer. This is useful when you need to record a time but also want to time different segments of that time as well. So, if you timed an event for ten minutes and could have multiple split times saved within those ten minutes.

The Easi-Stopwatch can record up to 40 split times, allowing you to capture moments of time without stopping the timer. This is great for timing different stages of a science experiment, recording lap times as you run around the track, seeing how long specific tasks take in a lesson or game, working out how long the introduction or summary was in a presentation or how long different talkers took to speak.

You can record and analyse the times collected and discuss which activities took longer and why.

How recording split times works

While the timer is running

- Press either of the buttons on the top of the stopwatch (top side buttons-see diagram above) This will save the current time as a split, but the stopwatch will continue running in the background.

Recording additional split times

- You can repeat the above process by pressing either of the top side buttons to save up to 40 split times.
- The display will show how many saved split times you have used out of the 40 available.



Easi-Stopwatches User Guide

(SP47468)

Viewing saved split times

- To review your split times, stop the timer using the start/pause button and press the left or right top side buttons to scroll forwards and backwards. This will allow you to view your saved split times.

Clearing split times

- To remove the split times timer and clear any saved times, hold down the left top button and then press and hold the start/pause button for 3 seconds.

Sleep Mode

The Easi-Stopwatch has a sleep mode to help conserve the battery life.

- If the timer is paused, it will automatically go to sleep after 10 minutes. You can wake it up by pressing the start/pause button and it will show the time that the stopwatch was paused on.
- If the timer is left running, after 10 hours it will go into sleep mode. To wake the stopwatch up, press the start/pause button. Your time will still be running and will display the new time.

Time activities and promote physical exercise with the TTS Easi-Stopwatches.